

FIND_NO	DESCRIPTION	631	632	633
1	HOLE PLUG	13693	13693	13693
2	BUTTON	3400	3400	3400
3	HAND KNOB	14680	14680	14680
4	SCREW	14305	14305	14305
5	BONNET	13845-8	13845-8	13845-8
6	NUT	14239	14239	14239
7	BUTTON	H713-21	H713-21	H713-21
8	SPRING	239-340224	H715-3	4422
9	DIAPHRAGM PLATE	14296	14296	14296
10	RING	14297	14297	14297
11	DIAPHRAGM	14505	14505	14505
12	O-RING	14613-11	14613-11	14613-11
13	RETAINER	13569-4	13569	13569
14	SEAT	13782-1	13782	13782
15	STEM	6489-6S	6489-6S	6489-6S
16	SPRING	6495	6495	6495
18	SPACER	14098-1	14098-1	14098-1
19	BODY	14298	14298	14298
20	GAUGE	GA081-00	GA082-00	GA083-00
21	SEAT	1222	1222	1222
22	RETAINER	1221	1221	1221
23	SPRING	1171	1171	1171
24	BODY	15967	15967	15967
25	O-RING	14613-14	14613-14	14613-14
26	O-RING	14613-13	14613-13	14613-13
27	PISTON ASSEMBLY	14286	14286	14286
28	O-RING	14613-55	14613-55	14613-55
29	SPRING	239-340860	239-340860	239-340860
30	JAM NUT	14302	14302	14302
31	BODY	14300	14300	14300
32	GAUGE	GA084-00	GA084-00	GA084-00
33	FILTER DISK	14491	14491	14491
38	SUPPORT	13568-1	13568-1	13568-1
39	WASHER	14557	14557	14557
40	RING	14543	14543	14543

